



### Permit to Work - Flow Chart - PTW-FC-6 (change of PIC for an active permit to work)

#### Immediate Transfer PTW-FC-6.1



Incoming PIC checks and verifies all isolations, PTW documentation, worksite conditions and delineation with the IP's.

#### Delayed Transfer PTW-FC-6.2



AO Identifies and approves the incoming PIC

#### Unplanned Transfer PTW-FC-6.3

